

9210 UCOUSTIC CABINET DIS-ASSEMBLY INSTRUCTIONS

TO DISMANTLE A FULLY BUILT 9210 CABINET – FIRST REMOVE FRONT AND REAR DOORS AND THEN THE SIDE PANELS ENSURING THEY ARE PLACED ON A FLAT SURFACE AND LEANT AGAINST A SOLID WALL TO AVOID ANY DAMAGE. THEN UNSCREW THE DEPTH SUPPORT RAILS AND THE INFIL PANELS, AGAIN ENSURING THESE ARE CAREFULLY PLACED ON A SMOOTH SURFACE TO AVOID ANY DAMAGE. ALSO ENSURE THAT ALL FIXINGS ARE KEPT TOGETHER!!



THEN REMOVE THE MOUNTING ANGLES AND YOU WILL BE LEFT WITH THE BARE FRAME. TO FURTHER DISMANTLE, REMOVE THE TOP COVER FOLLOWED BY EACH OF THE CORNER POSTS AND FINALLY REMOVING THE CASTORS FROM THE UNDERSIDE OF THE BASE IF REQUIRED. TO REASSEMBLE, PLEASE SEE ASSEMBLY INSTRUCTIONS.

